



Eddie Bauer® Shirt Jac

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Body Length	27	28	29	30	31	32	32.5	33
Chest	20	21.5	23	24.5	26	27.5	29.5	31.5
Sleeve Length	35.25	36	36.75	37.5	38.25	39	39.75	40.5

CHEST

Measured across the chest one inch below armhole when laid flat.

LENGTH

Measured from center front neck to hem.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.

SIZE CHART

	XS	S	M	L	XL	2XL	3XL	4XL
Chest	32-34	35-37	38-40	41-43	44-46	48-50	52-54	55-57

CHEST

With arms down at sides, measure around the upper body, under arms and over the fullest part of the chest.